

How to Measure a Cartridge

1. Measure outside diameter in inches, $\pm 1/32$ ".
2. Measure length (in inches, $\pm 1/16$ "") from end cap to end cap. Include end caps but do not include any handles or connectors.
3. Identify and describe end cap configuration top and bottom (i.e., open top/bottom, closed top, castle top, etc.).
4. If, for example, the top and/or bottom is "open," measure inside diameter in inches, $\pm 1/32$ ".
5. Record the OEM name and model of the filter the cartridge came out of (if possible).
6. Count the number of pleats (± 2). This determines square footage. Note whether there is a center core or not.